
Post Clamps


Equal/Unequal Dia., Perpendicular Configuration, Hole Pitch Selectable


Feature: Selectable shaft pitch between two posts for stands





Feature: By mounting below the clamp, fine manual adjustments are possible (Max. stroke 5mm recommended). Best suited for adjustments of cameras and sensors.






Recommended tolerances of fitting shafts for D1: g6, f8.



Thow to Use (Adjustable range is 5mm)



(1)Mount Part A below a post clamp to be adjustable.

(2)Install Part B on the threaded part of Part A


③After mounting the post clamp, position Part B with a hand or HEX wrench, adjust

the post clamp to a desired position by utilizing the thread pitch. (Stroke 5mm) ④Secure the post clamp by tightening the screw.

(The Set Screw can be used to temporarily fix the position before the final step (4).)

<Double Nut Type> Mount Part C on thread part of Part A after the step ①. Using the Part C, Double Nut mounting is facilitated. Can be used as a stopper when the post clamp is loosened Example "Economical clamping adjustment mechanism is needed." Best suited for these customer needs. Suitable for 1~2mm adjustments of cameras, etc.

"Fine vertical adjustments are needed."



Accessories


Hex Socket Head Cap Screw (Stainless Steel)

Hex Socket Head Cap Screw

Electroless Nickel Plating

Black Oxide

A wrench can be used for heavier objects



Fax 1-800-681-7402

(1-847-843-9107)

Phone 1-800-681-7475 (1-847-843-9105) MiSUMi

1-1884