
## **Blind Joint Components**

**Aluminum Extrusions** 


& Brackets

**Pre-Assembly Insertion Double Joint Kits** 




## **Blind Joint Components**

**Pre-Assembly Insertion Double Joint Kits, continued** 




## How to Use Pre-Assembly Insertion Double Joint Connection at the Corner

If HNTHSN6 is used instead of ② HNTTSN6-5, Pre-Assembly Insertion Double Joint can be used at the corner of the extrusion.



- Pre-Assembly Insertion Double Joint Kits / Offset Nut Type It is used when installing brackets with angle, truss brackets and angled extrusions.
- The allowable load is the same level as when the bracket is used.



Part Number		Extrusion	М	Р
Туре	No.	Used	IVI	r
HDJFSN	6	HFS6-3030	5	20.6
		HFS6-5050		40.6
		HFS6-6060		50.6
	8	HFS8-4040	6	25
		HFS8-8080		65
	8-45	HFS8-4545		29
		HFS8-5050		34
		HFS8-6060		44
		HFS8-9090		74

O Same shape of different surface treatment or material can be also used.

while adjusting the position