
Leveling Mounts for Aluminum Extrusions / Caster Kits for Doors

Compact



Rotary Type

Accessories for Aluminum Extrusions


Part Numb	er	М	•				Extrusions*	ı	Н	£1	ℓ_2	В	Allowable Vertical Load	Mas	s (g)
Туре	D	(Coarse)		A		EXITUSIONS"	HNFJN	HNFJR	CI	CZ	В	(kN)	HNFJN	HNFJR	
	28	8	20	50		100	30 Square	17.7	28.2	5.2	6.5	13	6.5	48	50
	38	12	3	30	80	100	40 Square	23	35.4	7.4	10	19	13	55	59
HNFJN	40	8	20	50		100	EO Carroso	20.7	33.2	5.2	6.5	13	6.5	77	73
HNFJR Rotary Type	48	12	3	30	80	100	50 Square	23	35.4	7.4	10	19	13	90	85
58	8	20	50		100	60.0	20.7	33.2	5.2	6.5	13	6.5	121	115	
	12	3	30	80	100	60 Square	23	35.4	7.4	10	19	13	133	129	

O Can be used for the end of extrusions with one tapped hole alterations for mounting. It cannot be directly mounted to the extrusions with multiple tapped holes on their ends.










Mount directly to each single slot type to prevent the



Part Nun	nber	Futuraiana	Caster Allowable Load	Mass
Туре	No.	Extrusions	Allowable Load N	(g)
COCM	6	30 Square	250	100
SQCM	8	40 Square	350	160


							Comp	ponent			
No.		Pla	ate			Dedicate	ed Caster		Extrusion	Mounting	
	В	W	T	d	D	Н	Quantity	Mounting Screw	Quantity	Nut	Quantity
6	30	15		7	F0.	00		SCB6-14		HNTP6-6	0
8	40	20	ь	8.5	50	68		SCB8-18	2	HNTP8-8	2



Part Number Example




Anchors for Aluminum Extrusions



Part Number	r	Mass	Extrusions	Screws / Nuts			н	-	G	w		4	0	
Туре	No.	g	(Series)	Screws	Quantity	Nuts	Quantity	п	Г	G	VV		a	į.
HECANIK	6	318	HFS6	CBM6-15		HNTT6-6		100	60	40	30	86.5	7	40
HFSANK	8	512	HFS8*	CBM8-15	2	HNTT8-8	2	120	80	50	40	96.5	10	60
HECANION	6	624	HFS6	CBM6-15	,	HNTT6-6	4	100	60	40	33.2	86.5	7	40
HFSANKW	8	1020	HFS8*	CBM8-15	4	HNTT8-8	4	120	80	50	43.2	96.5	10	60

^{*}Not applicable to HFS8-45.

O Screws and nuts are not included.



Part Number		Mass	Extrusions	Screws / Nuts					
Туре	No.	g	(Series)	Screws	Quantity	Nuts	Quantity		
HEDANIK	6	118	HFS6	CBM6-20		HNTT6-6	3		
HFDANK	8	147	HFS8	CBM8-28	3	HNTT8-8			

Part Number Example Part Number HFSANK6

*Not applicable to HFS8-45.

O Screws and nuts are not included.





Alteration	Code	Spec.	Applicable Anchor
Applicable Screw			HFSANK6
		Set of screws and nuts for mounting the anchor to	HFSANK8
	SET SST	an aluminum extrusion. Anchor bolts are not included. When SST is specified, screw and nut will be the set	HFSANKW6
/ Nut Set	(Stainless Steel)	of stainless steel. (Ex.) Screw: SCB6-15	HFSANKW8
		Nut: HNTTSN6–6	HFDANK6
			HFDANK8