









Order

Part Number
M-SJP-20A









## Applications

- If the nut cannot be loosened using the extend socket, insert the pipe type jig into the handle and turn the jig.
- When performing maintenance on the molding machine, check the Sodick's instruction manual and implement appropriate safety measures against burns and electric shock, etc.
- Perform the necessary preparations for removing the plasticizing cylinder, such as removing the plasticizing motor and non-return unit.
- The jig can also be used for various other applications, but be especially careful during use to prevent jigs and tools from slipping off or being damaged.
- Extend socket ► P.69